

Tech Tip



Tech Tip
NO. 00007 PAGE 1 OF 1

N17xx NuVinci HUB

Shift Rod

June 25, 2007 REV. 01

PART NUMBERS:

0160 Shift Rod

DESCRIPTION:

Shift Rod Lubrication to Prevent Corrosion

SUGGESTED MAINTENANCE:

After extended use in environments where the NuVinci hub may be exposed to water, it may be necessary to lubricate the exposed end of the shift rod to prevent excessive corrosion. The shift rod may be partially removed for this operation to facilitate cleaning. The following precautions apply:

- ONLY the areas indicated below should be cleaned and lubricated.
- DO NOT allow solvent or cleaning solution to run down the shift rod and into the hub.
- DO NOT tip the hub with the shift rod facing downward, or the hub's lubricant may spill out.

Clean shift rod. Lubricate splines and O ring with multi-purpose grease, prior to re-installation.

Lubricate with Multi-Purpose Grease on Shift Rod Splines and O Ring

